

## 1 Core Overview

The External Bus to Avalon Bridge provides a simple interface for a peripheral device to connect with the Avalon<sup>®</sup> Switch Fabric as a master device. The Bridge creates a bus-like interface to which one or more “master” peripherals can be connected.

## 2 Functional Description

Figure 1 shows how the External Bus to Avalon Bridge provides a connection between the Avalon Switch Fabric and an external master peripheral.




Figure 1. Usage of the External Bus to Avalon Bridge


From the Avalon Switch Fabric’s perspective, the External Bus to Avalon Bridge is a master device, because it initiates and controls read/write transfers on the Avalon Switch Fabric. From the external peripheral’s perspective, the Bridge is a slave device.

The bus signals provided are:


- **Address** —  $k$  bits (up to 32). The address of the data to be transferred. The address is aligned to the data size. For 32-bit data, the address bits **Address**<sub>1-0</sub> are equal to 0. The **ByteEnable** signals can be used to transfer less than 4 bytes.
- **Read** — 1 bit. Indicates that the data transfer is a Read operation.
- **Write** — 1 bit. Indicates that the data transfer is a Write operation.
- **ByteEnable** — 16, 8, 4, 2, or 1 bits. Each bit indicates whether or not the corresponding byte should be read or written. These signals are active high.
- **WriteData** — 128, 64, 32, 16, or 8 bits. The data to be written to the peripheral device during a Write transfer.
- **ReadData** — 128, 64, 32, 16 or, 8 bits. The data that is read from the peripheral device during a Read transfer.
- **Acknowledge** — 1 bit. Used by the peripheral device to indicate that it has completed the data transfer.

The bus is synchronous — all bus signals must be read by the master peripheral on the rising edge of the clock. A bus transfer happens when either **Read** or **Write** is high.

Figure 2 shows an example system using the Bridge that connects a Nios® II system implemented on the Intel® DE2 Board to a master peripheral.



(a) External bus signals



(b) External bus timing diagram

Figure 2. The External to Avalon Bus Bridge signals

### 3 Instantiating the Core in Platform Designer

Designers use the External Bus to Avalon Bridge's configuration wizard in Platform Designer to specify the desired features. Two parameters need to be specified:

**Data Width** — The number of data bits involved in a transfer. The Bridge supports data widths of 8, 16, 32, 64, and 128 bits.

**Address Range** — The addressable space supported by the Bridge. It is possible to specify the address range of 1, 2, 4, 8, 16, 32, 64, 128, 256, 512, and 1024, in either bytes, kilobytes (kB) or megabytes (MB).

Copyright © Intel Corporation. All rights reserved. Intel, the Intel logo, Altera, Arria, Avalon, Cyclone, Enpirion, MAX, Nios, Quartus and Stratix words and logos are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. Intel warrants performance of its FPGA and semiconductor products to current specifications in accordance with Intel's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Intel assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Intel. Intel customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

\*Other names and brands may be claimed as the property of others.